
ADJUST ANGULAR POSITION BY CLAMPING AT BALANCE ADJUSTER AND LOVER LOCK NUTS



SIGN MOUNT - TYPE A - SINGLE SPAN WIRE
NOT TO SCALE